

Site-

Site- :

1. “Securiton”.

The screenshot displays the Securiton software interface. At the top left, there is a field for 'СКУД "Securiton" 1' and a 'Компьютер' dropdown menu currently set to 'Computer'. To the right, the 'Версия модуля' (Module version) is shown as '1.0.0.4'. Below these, there are input fields for 'IP адрес' (IP address), 'Порт' (Port) set to '5000', and 'Пользователь' (User) set to '1'. A checkbox labeled 'Динамическая пересылка СПР' (Dynamic forwarding of SPR) is present. A button labeled 'Переподключиться' (Reconnect) is highlighted with a red oval. Below the main configuration area, there are several buttons: 'Записать настройки СПР' (Save SPR settings), 'Записать конфигурацию' (Save configuration), 'Синхронизировать время' (Synchronize time), 'Начать получение конфигурации' (Start receiving configuration), 'Начать фон. удаление данных неактуальных пользователей' (Start background deletion of data for inactive users), and 'Начать фон. удаление данных неактуального оборудования' (Start background deletion of data for inactive equipment). At the bottom, there are 'Применить' (Apply) and 'Отменить' (Cancel) buttons.

2. .

Site- .