

FSG

, FSG, :

1. FSG.

1

FSG 1

Control

1.9.9.9

Computer


☐ Disable

LOCALHOST

Start device search

2. Start device search.

FSG, .



, , , , , FSG.

:

1. FSG panel IP- FSG.

1.1

FSG panel 1.1

FSG

☐ Disable

FSG 1

IP connection info

IP address 192.168.0.2

Port 47808

2. FSG device .

1.1.0

FSG device 1.1.0

FSG panel

☐ Disable

FSG panel 1.1

Settings

Instance 0

Device info

Model name

Vendor name

Firmware

Device name

Vendor id 123

Software

Service mode

Password

Set service mode

3. , FSG, Out of service, . , . .

1.1.0.0 FSG analog value

FSG device ☐ Disable

FSG device 1.1.0

Device id 0 ☐ Out of service

Rule

Info

Device name

4. FSG binary input .

1.1.0.0 FSG binary input

FSG device ☐ Disable

FSG device 1.1.0

Device id 0 ☐ Out of service

Info

Device name

Device type 0

States

Value below 500 Ohm 1. Active

Value 500-1500 Ohm 2. Inactive & Fault

Value 1500-2500 Ohm 3. Active & Fault

Value 2500-3500 Ohm 4. Inactive & Alarm

Value above 3500 Ohm 5. Active & Alarm