

AxisQ7401

AxisQ7401 :

1. Setup > System Options > Ports & Devices > I/O Ports

AXIS

COMMUNICATIONS

AXIS Q7401 Video Encoder

Live View | Setup | Help

Basic Setup

Video & Audio

Live View Config

PTZ

Applications

Events

Recordings

System Options

Security

Date & Time

Network

Storage

Ports & Devices

I/O Ports

COM Port

Maintenance

Support

Advanced

About

I/O Ports

I/O Port Type*	Name	Normal state is...	Current Status
1 Input	RING	Open circuit	Open circuit
2 Input	Input 2	Open circuit	Open circuit
3 Input	Input 3	Open circuit	Open circuit
4 Input	Input 4	Open circuit	Open circuit

*If the port is used in an event, it is not possible to switch between input and output until the event is changed or removed.

SaveReset

2. , DBL " " , 0 Axis Q7401.
3. : (Input) Normal State is: open circuit (-).
4. , Setup >System Options > Port & Devices > I/O Ports , Active.