


, SIP-

, SIP-, :

1. , .



2. > .

3. , .

The image shows a software configuration window with a light blue background. At the top, there is a rounded rectangular box containing three input fields. The first field is labeled 'Номер' (Number) and contains the value '1'. The second field is labeled 'Название' (Name) and contains the text 'Устройство видеоввода SIF'. The third field is a dropdown menu labeled 'Сервер' (Server) with a downward arrow. Below this box, the main area of the window is empty. At the bottom, there is a dark blue bar containing two buttons: 'Применить' (Apply) and 'Отменить' (Cancel). The 'Применить' button is highlighted with a black oval.

Номер	1
Название	Устройство видеоввода SIF
Сервер	▼

Применить Отменить

4.

Пользователи Программирование

1 1 Устройство видеоввода SIP

Компьютер ☐ Отключить

Сервер

1 Тип: SIP

PCI канал: 00

Сигнал: PAL

Разрешение: Стандартное

Скорость: - макс
- мин

2 IP: 192.168.1.2

Порт: 5060

3 Имя: 12345

Пароль: xxxx

☐ Активизировать watchdog

☐ Использовать настройки устройства

Основные настройки

4

Применить Отменить

5. SIP (1).

6. IP- IP- SIP- (2).

7. (3).




!

(), SIP-.

8. (4).

9. , . SIP-.



10. 1-9 SIP-.

, SIP-, .