

NAT

NAT RTSP Web (. RTSP RTSP).

, RTSP NAT:

The screenshot shows the configuration window for the RTSP Web service. At the top, there is a section for the server name and location, with '1' in the ID field, 'RTSP Сервер 1' in the name field, and 'LOCALHOST' in the location dropdown. Below this are checkboxes for 'Компьютер' and 'Отключить'. The main window has two tabs: 'Основные настройки' (selected) and 'Дополнительные настройки'. Under 'Основные настройки', there are checkboxes for 'Режим совместимости с плеером VLC' and 'Использовать дорожку субтитров'. Below these is a label 'Ip-интерфейс источника:' followed by a dropdown menu set to 'ANY'. A blue box highlights the 'Настройки NAT' section, which contains an 'IP адрес:' field set to '10.0.12.139' and a 'Порт:' field set to '1001'.

10.0.12.139 – IP- .

1001 – .

127.0.0.1 – .

559 – RTSP .

80 – Web .

:

GET http://IP-:/getliveurl?cameraid={cameraid}

:

cameraid		

:

GET http://127.0.0.1:80/getliveurl?cameraid=1

:

NAT- Web :

```
{
    "rtspurl": "rtsp://127.0.0.1:559/archive?id=1"
}
```

NAT- Web :

```
{
    "rtspurl": "rtsp://10.0.12.139:1001/archive?id=1"
}
```

:

id	