

Noder EE12/EWE4

	NODER alexander.baranov@ru.axxonsoft.com IPDROM www.ipdrom.ru
	Ethernet

EWE4		• 4 2 () • 1 024 000 • 2 048 000 • – (AntiPassBack). • – (AntiPassBack).
EE12		• 10 5 () • 1 024 000 • 2 048 000 • – (AntiPassBack). • – (AntiPassBack).
MD-R/W	Mifare DESFire	• : EWE4, EE12 • : • MD-R - RS-485 (AES-256) • MD-W - Wiegand • :
MDK-R	Mifare DESFire	• : EWE4, EE12 • : RS-485 • :
IO16RS		• : EWE4, EE12 • : 16 • : 1 – 4 • : 1 – 4 • : 1 – 64
RS->Wiegand		• (Wiegand-RS485-Wiegand) 4 (, , 1, 2). Wiegand 1000 CAT 5e. • : , Wiegand.
MD-USB		• : MIFARE DESFire • : USB

:

-	
"" - NODER (EWE4)	1 4
"" - NODER (EE12)	1 12