

Itv_var

Itv_var .
:

```
function Itv_var (globalvar : String) : String
```

Globalvar – . . . : String, (String) Windows.

 .
, Windows. HKEY_USERS\S-1-5-21-...\Software\VMSScript\VMSSCRIPT HKEY_CURRENT_USER\Software\VMSScript\VMSSCRIPT.

. 1 ("bright") 10 cam10bright. 2 1-4 cam10bright.

```
if (Event.SourceType == "MACRO" && Event.Action == "RUN")  
{  
    if(Event.SourceId == "1")  
    {  
        Itv_var("cam10bright") = GetObjectParam("CAM", "10", "bright");  
    }  
    if (Event.SourceId == "2")  
    {  
        var cam10bright = Itv_var("cam10bright");  
        for(i=1; i<=4; i=i+1)  
        {  
            SetObjectParam("CAM", i, "bright", cam10bright);  
        }  
    }  
}
```