

RR GPU


DetectorPack 3.10 (RR) (. DetectorPack) , GPU Axxon Next.

RR GPU :

1. (.).

 !
 , GPU, .


2. GPU_CACHE_DIR (. 10.), , D:\AN_GPU_cache.

 !
GPU_CACHE_DIR (: D:\), (1) , (2) () (3).


3. : C:\Program Files\Common Files\AxxonSoft\DetectorPack\RoadarGpuCacheGenerator.exe **Enter**.

4. , y.

- a. lpr recognition – ;
- b. vehicle recognition – .



lpr recognition . . -1.

```
Please choose the countries...
0. AM      13. DK      26. KZ      39. RO
1. AR      14. EE      27. LT      40. RU
2. AT      15. EG      28. LU      41. SE
3. AZ      16. ES      29. LV      42. SI
4. BE      17. FI      30. MD      43. SK
5. BG      18. FR      31. MM      44. TJ
6. BN      19. GE      32. MT      45. TM
7. BR      20. GR      33. MX      46. UA
8. BY      21. HR      34. MY      47. UZ
9. CY      22. HU      35. NL      48. VN
10. CZ     23. IE      36. PE
11. DE     24. IT      37. PL
12. CO     25. KG      38. PT

Enter the codes of the countries, separated by enter:
Enter -1 when you are done
Enter your choice: 24
Enter your choice: FR
Enter your choice: 11
Enter your choice: -1
```

5. ID GPU (.) Enter.

```
Please enter device ordinal mentioned in the list above, to generate cache for...
NOTE: the device should have MORE than 1.4GB of free GPU memory in order to success
NOTE: this application will fail if the GPU is being used by other applications
please quit all such applications before starting the caching process.
Availble choices: [0-0]
Enter your choice: _
```

, 30. , GPU Nvidia.

RR RR GPU .



!

RR (. [DetectorPack](#)) GPU Nvidia .