

Itv_var

Itv_var .

:

```
function Itv_var (globalvar : String) : String
```

Globalvar – . . . : String, (String) Windows.



.

, Windows. HKEY_USERS\S-1-5-21-...\Software\VMSScript\VMSSCRIPT HKEY_CURRENT_USER\Software\VMSScript\VMSSCRIPT.

. 1 ("bright") 10 cam10bright. 2 1-4 cam10bright.

```
if (Event.SourceType == "MACRO" && Event.Action == "RUN")
{
    if(Event.SourceId == "1")
    {
        Itv_var("cam10bright") = GetObjectParam("CAM", "10", "bright");
    }
    if (Event.SourceId == "2")
    {
        var cam10bright = Itv_var("cam10bright");
        for(i=1; i<=4; i=i+1)
        {
            SetObjectParam("CAM", i, "bright", cam10bright);
        }
    }
}
```